

TROUBLESHOOTING

Basic Troubleshooting

1. Troubleshooting occurring with the automatic transmission can be caused by either the engine, electrical control or the transmission itself. These three areas should be distinctly isolated before proceeding with troubleshooting.
2. Troubleshooting should begin with the simplest operation, working up in order of difficulty, but first determine whether the trouble lies within the engine, electrical control or transmission.
3. Proceed with the inspection as follows:

