



Park Neutral Position Switch INSPECTION OF PARK/NEUTRAL POSITION SWITCH

Inspect that there is continuity between each terminals.

Terminal Shift Position	В	N	PL	RL	NL	DL	2L	LL	С
Р	0	0	0_						-0
R				0-					-0
N	0-	0			0				0
D						0-			-0
2							0-		0
L								0-	0